

# Alpha<sup>®</sup> Serial Clock User Manual

For the most recent update of this manual, go to:  
<http://www.adaptivedisplays.com/Pages/techdoc.htm>



— *Make sure DIP switch #8 is set to OFF (see page 10)*

**ADAPTIVE**

© 1997-2001 Adaptive Micro Systems  
Form No. 9703-3006A  
11/21/2001

**NOTE:** Due to continuing product innovation, specifications in this document are subject to change without notice.

Copyright © 1997-2001 Adaptive Micro Systems, Inc. All rights reserved.

Adaptive Micro Systems

7840 North 86th Street

Milwaukee, WI 53224 USA

414-357-2020

414-357-2029 (fax)

<http://www.adaptivedisplays.com>

The following are trademarks of Adaptive Micro Systems: Adaptive, Alpha, AlphaNet plus, AlphaEclipse, AlphaPremiere, AlphaTicker, AlphaVision, AlphaVision InfoTracker, Automode, BetaBrite, BetaBrite Director, BetaBrite Messaging Software, Big Dot, PPD, Smart Alec, Solar, TimeNet.

The distinctive trade dress of this product is a trademark claimed by Adaptive Micro Systems, Inc.

# Contents

Introduction .....	1
Power supply (AC adapter) .....	1
Master/Slave modes .....	2
Setting the time .....	3
Bright/Dim switch .....	3
Stand alone operation .....	3
Network configurations—Adding serial clocks to an Alpha® network .....	4
Time zone adjust feature .....	6
Wall mounting .....	8
Countertop or desk mounting .....	8
Using end-of-line terminators with serial clocks .....	9
Setting the #5 DIP switch .....	10
Setting the #8 DIP switch to OFF .....	10
Clock specifications .....	11

## *Serial Clock Warranty*

Adaptive Micro Systems, Inc. warrants to the original purchaser that the sign, keyboard and power supply will be free of defects in workmanship and materials for a period of ninety (90) days from the date of purchase.

Adaptive Micro Systems, Inc. will without charge, repair or replace, at its option, defective product or component parts upon delivery to the factory service department accompanied by proof of the date of purchase in the form of a sales receipt.

This warranty does not apply in the event of any misuse or abuse of the product, or as a result of any unauthorized repairs or alterations. This warranty does not apply if the serial number is altered, defaced or removed from the sign. Incandescent lamps used in incandescent products are not covered by this warranty.

The purchase price of this product does not include, from Adaptive Micro Systems, Inc., any on-site support, service or maintenance.

Local ordinances prohibiting the use of flashing signs may exist in some locations. Compliance with local ordinances is the sole responsibility of the customer.

To obtain warranty coverage, this product must be registered. Please complete the enclosed warranty registration card and mail it to Adaptive Micro Systems, Inc.

## *How to Obtain Warranty Service on Alpha<sup>®</sup> Products*

To obtain warranty service on Alpha<sup>®</sup> products:

1. Contact the dealer/distributor from whom the product was purchased. If you do not know where the product was purchased, contact Adaptive Micro Systems Customer Service at 414-357-2020.
2. If the dealer/distributor cannot service the product, obtain a Return Merchandise Authorization (RMA) number through that company. An RMA number is required to obtain warranty service.
3. Fill out the Return Merchandise Authorization (RMA) Form on the following page. To obtain warranty service, this form including the RMA number must accompany the product.
4. Follow return instructions on the RMA form to return to Adaptive Micro Systems, Inc.

# Return Merchandise Authorization Form

RMA Number: \_\_\_\_\_

Date of Purchase: \_\_\_\_\_

Company Name: \_\_\_\_\_

Contact Person: \_\_\_\_\_

Address: \_\_\_\_\_

\_\_\_\_\_

Phone Number: \_\_\_\_\_

Description of Problem: \_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

## Return Instructions:

- Step 1: Obtain an RMA number from your dealer/distributor.
- Step 2: Fill out this form and include proof of purchase receipt if product is under warranty.
- Step 3: Pack this form and the product in the original carton (or a suitable replacement). Please write the RMA number on the outside of the package. Any damage to the product during shipment is the responsibility of the freight company or the owner of the product.
- Step 4: Ship the package, postage/shipping prepaid to:

Adaptive Micro Systems, Inc.

Attn: RMA No. \_\_\_\_\_

7840 North 86th Street

Milwaukee, WI 53224

PLEASE WRITE THE RMA NUMBER ON THE LABEL OF THE SHIPPING BOX - THANK YOU.

## *EMI Compliance*

The Alpha<sup>®</sup> serial clock complies with Part 15 of the FCC Rules.

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These are limits designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses and can radiate radio frequency energy and if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

Changes or modifications made to the Alpha<sup>®</sup> serial clock that have not been expressly approved by Adaptive Micro Systems, Inc. could void your authority to operate the Alpha<sup>®</sup> serial clock.

NOTE: Damage to clock can occur if exposed to direct sunlight or moisture. Do not expose clock to direct sunlight or moisture. Clock is for indoor use only—do not use outdoors.

NOTE: Damage to clock can occur if clock overheats. Make sure that there is adequate ventilation and air flows on all sides of the clock to avoid overheating.

Clock has no customer serviceable parts. Return to manufacturer if service is required.

## Introduction

The Alpha<sup>®</sup> serial clock displays the time in either 12-hour or 24-hour mode using a 4-inch LED display. The clock can be used all by itself or it can be networked with other Alpha<sup>®</sup> clocks or Alpha<sup>®</sup> signs. In a network, one clock (or a PC attached to the network) is used to synchronize all the other clocks to the same time.

Used by itself, the Alpha<sup>®</sup> serial clock should be set to *master mode*. In a network composed of all Alpha<sup>®</sup> serial clocks, one clock should be set to master mode and the other clocks set to slave mode. In a network with a PC that is connected to Alpha<sup>®</sup> clocks and Alpha<sup>®</sup> signs, all the clocks should be set to *slave mode*.

## Power supply (AC adapter)

The clock is equipped with a small AC adapter with an 18-foot power cord. Connect the power cord to the adapter plug receptacle on the backside of the clock (See Figure 1: Serial Clock—Rear Panel) **before** plugging the adapter into a standard 120V wall outlet.




Figure 1: Serial Clock—Rear Panel

## *Master/Slave modes*

The Alpha<sup>®</sup> serial clock can either operate in master or slave mode. A clock set to master mode sends out the time once each minute to all of the other clocks on a network. A clock set to slave mode is ready to receive the time from the master clock or a PC (personal computer). On a network, only one clock should be set to master—all other clocks should be set to slave mode. On a network attached to a PC, all clocks should be set to slave mode.

The master/slave switch is located on the back of the clock, next to the 12/24 hour switch (See Figure 1: Serial Clock—Rear Panel).

**To change the master/slave mode settings, first remove the adapter from the wall outlet, set the master/slave switch to the desired setting, and re-insert the adapter into the wall outlet.**

The slave mode setting can also be set using the #5 DIP switch. If the #5 DIP switch is set to ON, the clock will operate in slave mode, regardless of the setting of the master/slave switch. If the #5 DIP switch is set to OFF, the clock will operate in the mode specified by the master/slave switch on the back of the clock. This DIP switch capability is provided in order to make it more difficult for unauthorized personnel to change a clock from the slave mode to the master mode. (See Figure 6: Setting the DIP Switches on page 10 for more information.)



## Setting the time




Figure 2: Serial Clock—Front Panel

To set the time of the master clock, use the HOUR or MINUTE buttons on the front lower right side of the clock (See Figure 2: Serial Clock—Front Panel). The HOUR and MINUTE buttons do not operate if the clock is set to slave mode.

To set the hours, press the HOUR button until the desired number is displayed. There is no AM/PM option. If the clock is in 12-hour mode, 1-12 will be the only hours displayed. If the clock is in 24-hour mode, 0-23 will be the hours displayed. Use the 12/24 Hour Switch on the back of the clock (See Figure 1: Serial Clock—Rear Panel on page 1) to set the clock to either 12-hour or 24-hour mode.

To set the minutes, press the minute button until the desired number is displayed. Each press of the HOUR or MINUTE button will increase the number displayed by one. Pressing and holding the HOUR or MINUTE button down will increase the numbers displayed automatically.

### Bright/Dim switch

A bright/dim switch, located on the back of the clock (See Figure 1: Serial Clock—Rear Panel on page 1), allows you to switch between a bright or a dim display mode to suit your preference.

### Stand alone operation

Clocks not attached to a network must be set to master mode. The time can be set using the HOUR and MINUTE buttons on the front of the clock.


### Network configurations—Adding serial clocks to an Alpha® network

Alpha® serial clocks can be connected together with each other or in a mix of Alpha® signs. Also, like an Alpha® sign, an Alpha® serial clock must be terminated when it is the last device on a network.

In a network, one clock (or a PC attached to the network) is used to synchronize all the other clocks to the same time. In an network composed of all Alpha® serial clocks, one clock should be set to *master mode* and the other clocks set to *slave mode*

Table 1: Networking Alpha® serial clocks  
(Example 1 — A network of all clocks)

In this example all-clock network, one of the clocks must be set to master mode. All the other clocks on the network must be set to slave mode. Also, the *first* and *last* clocks on the network must be terminated.




Item	Part #	Description
A	1088-9107	End-of-line (EOL) terminator. (An EOL must be plugged into the <i>left</i> —as you face the back of the clock—RJ11 phone jack.)
B	—	Ferrite (ferrite end towards sign)
C	1088-8624	8 foot, 4-conductor RS485 cable
	1088-8636	1 foot, 4-conductor RS485 cable
D	4331-0602	Modular Network Adapter
E	1088-8000	RS485 cable

In a network with a PC that is connected to Alpha® clocks and Alpha® signs, all the clocks should be set to *slave mode*. For more information on using the Alpha® serial clock in a network, see the document **Network Configurations** (p/n 9708-8046):

**Table 2: Networking Alpha® serial clocks**  
 (Example 2 — A network of clocks attached to a PC)

Unlike the previous all-clock network, in this example, a PC is connected to the network. All the clocks on the network must be set to slave mode. Also, the *last* clock on the network must be terminated.



Item	Part #	Description
A	1088-9107	End-of-line (EOL) terminator. (An EOL must be plugged into the <i>left</i> —as you face the back of the clock—RJ11 phone jack.)
B	—	Ferrite (ferrite end towards sign)
C	1088-8624	8 foot, 4-conductor RS485 cable
	1088-8636	1 foot, 4-conductor RS485 cable
D	4331-0602	Modular Network Adapter
E	1088-8000	RS485 cable
F	1088-1111	Converter Box III
G	1088-8634	10 foot, 9 pin-to-9 pin, type "A9" RS232 cable
H	—	serial port DB25-to-DB9 RS232 adapter (may be required by your computer)

## Time zone adjust feature

Some Alpha<sup>®</sup> serial clocks have a time zone adjust feature. This lets you display the time in different time zones on your networked clocks. For example, you could network four clocks in an office and use them to show the time across the continental United States. Clocks with this feature do not have the ability to set a serial address. This feature may not be available on all Alpha<sup>®</sup> serial clock.

To set the time zone adjust feature:

1. Decide which time zone(s) you are going to display. Figure out how many hours ahead (+) or behind (-) the time zones are from your current time. This is the number of offset hours. Use the DIP Switch Settings table below to determine the correct switch settings for switches numbered 1-4 and 7. For example, if you are in the Central Time Zone and you wish to display the time in the Eastern Time Zone, the offset hours would be "+1". The switch settings would be:

DIP 1=ON

DIP 2=OFF

DIP 3=OFF

DIP 4=OFF

DIP 7=OFF

2. Unplug the adapter from the wall outlet.
3. Use a Phillips screwdriver to remove the back plate from the serial clock.
4. Locate the DIP switches numbered 1-4 and 7. (See Figure 3: DIP Switches 1-4 and 7).
5. Use the tip of a pen or small screwdriver to turn the DIP switches on or off as directed by the table below.
6. Reattach the back plate and plug the adapter back into the wall outlet.




Figure 3: DIP Switches  
1-4 and 7

**NOTE:** If you have a network of all clocks, one clock must be set to master mode. All the other clocks on the network must be set to slave mode. If your network is connected to a PC, all clocks on the network must be connected to the slave mode. (See Setting the #5 DIP switch on page 10 for more information.)

DIP Switch Settings  
(DIP #8 should always be OFF — see page 10.  
To set DIP #5 — see page 10.)

Offset Hours	DIP 1	DIP2	DIP3	DIP4	DIP7		Offset Hours	DIP 1	DIP2	DIP3	DIP4	DIP7
+0	OFF	OFF	OFF	OFF	OFF		-0	OFF	OFF	OFF	OFF	ON
+1	ON	OFF	OFF	OFF	OFF		-1	ON	OFF	OFF	OFF	ON
+2	OFF	ON	OFF	OFF	OFF		-2	OFF	ON	OFF	OFF	ON
+3	ON	ON	OFF	OFF	OFF		-3	ON	ON	OFF	OFF	ON
+4	OFF	OFF	ON	OFF	OFF		-4	OFF	OFF	ON	OFF	ON
+5	ON	OFF	ON	OFF	OFF		-5	ON	OFF	ON	OFF	ON
+6	OFF	ON	ON	OFF	OFF		-6	OFF	ON	ON	OFF	ON
+7	ON	ON	ON	OFF	OFF		-7	ON	ON	ON	OFF	ON
+8	OFF	OFF	OFF	ON	OFF		-8	OFF	OFF	OFF	ON	ON
+9	ON	OFF	OFF	ON	OFF		-9	ON	OFF	OFF	ON	ON
+10	OFF	ON	OFF	ON	OFF		-10	OFF	ON	OFF	ON	ON
+11	ON	ON	OFF	ON	OFF		-11	ON	ON	OFF	ON	ON
+12	OFF	OFF	ON	ON	OFF		-12	OFF	OFF	ON	ON	ON
+13	ON	OFF	ON	ON	OFF		-13	ON	OFF	ON	ON	ON
+14	OFF	ON	ON	ON	OFF		-14	OFF	ON	ON	ON	ON
+15	ON	ON	ON	ON	OFF		-15	ON	ON	ON	ON	ON

## Wall mounting




Figure 4: Serial Clock—Side View

1. Locate the keyhole slots on the back of the clock, at either end. The slots are placed six inches apart (See Figure 1: Serial Clock—Rear Panel on page 1).
2. Install two #8 screws into the wall/mounting surface, six inches apart. Use the type of screws and anchoring methods appropriate for the mounting surface. For example, use wood screws if you are mounting to a wood surface. (These screws are not supplied.) Make sure that the heads of the screws are placed at least 3/8 of an inch from the wall.
3. Insure that the plate and the feet are facing in, towards the backside of the clock (See Figure 4: Serial Clock—Side View).
4. Hang the clock on the two screws located on the wall/mounting surface, using the keyhole slots.

## Countertop or desk mounting

1. Remove the screw and plate on the backside of the clock (See Figure 1: Serial Clock—Rear Panel on page 1).
2. Turn the plate over so that the “feet” protrude out (away) from the backside of the clock (See Figure 4: Serial Clock—Side View). The plate can be adjusted up or down to obtain the desired viewing angle.
3. Replace the screw and stand the clock upright.

## Using end-of-line terminators with serial clocks




Figure 5: Location of DIP Switches and J5 Jumper

End-of-Line (EOL) Terminators help provide stable transmissions across an RS485 network. They should be inserted into the RJ11 ports on the last EMC or the last clock on an RS485 transmission line. Before inserting an EOL Terminator into the RJ11 port on a serial clock, the J5 jumper on the serial clock needs to be moved. EOL Terminators (p/n 1088-9107) must be ordered separately.

To change the location of the J5 jumper:

1. Unplug the adapter from the wall outlet. Use a Phillips screwdriver to remove the back plate from the serial clock.
2. Locate the J5 jumper on the backside of the serial clock (See Figure 5: Location of DIP Switches and J5 Jumper).
3. Use your fingers or a needle-nose pliers to carefully remove the jumper from positions 1 and 2 (See Figure 5: Location of DIP Switches and J5 Jumper). Make sure not to drop the jumper because it could fall into the serial clock's case. Place the jumper into positions 2 and 3.
4. Reattach the back plate to the serial clock.
5. The EOL terminator must be inserted into the RJ11 port on the left, closest to the DIP switches (See Figure 5: Location of DIP Switches and J5 Jumper).
6. Plug the adapter into a 120V outlet.
7. For more information on using EOL terminators, consult the **Network Configurations** (P/N 9708-8046).

## Setting the #5 DIP switch




Figure 6: Setting the DIP Switches

If the #5 DIP Switch is turned on, the clock will operate in slave mode, regardless of the setting of the master/slave switch.

To change the #5 DIP switch settings:

1. Unplug the adapter from the wall outlet.
2. Use a Phillips screwdriver to remove the back plate from the serial clock.
3. Locate the #5 DIP switch (See Figure 6: Setting the DIP Switches).
4. Use the tip of a pen or small screwdriver to turn the DIP switch ON or OFF. The clock is set to OFF when the clock is shipped from the manufacturer.
5. Reattach the back plate to the serial clock.
6. Plug the adapter into a 120V outlet.

**NOTE:** Steps 1 and 6 (above) must be done in order for changes to the DIP switch settings to take effect.

## Setting the #8 DIP switch to OFF

If the #8 DIP Switch is turned on, the clock will not operate properly. So, if #8 DIP switch is on, turn it off this way:

1. Unplug the adapter from the wall outlet.
2. Use a Phillips screwdriver to remove the back plate from the serial clock.
3. Locate the #8 DIP switch (See Figure 6: Setting the DIP Switches).
4. Use the tip of a pen or small screwdriver to turn the #8 DIP switch OFF.
5. Reattach the back plate to the serial clock.
6. Plug the adapter into a 120V outlet.



*Clock specifications*

Clock Dimensions:	3.5" x 7.1" x 2.2" (34.3 cm x 18.0 cm x 5.6 cm) Length x Height x Depth
Weight:	1.7 lbs. (0.78 kg) - clock 1.1 lbs. (0.50 kg) - AC adapter
Numeral Height	4" (10.2 cm)
Power:	Utilizes 30 Watt transformer, UL Listed, CSA Certified, 120 VAC (transformer input voltage range is 100-130 VAC)
Battery:	Built-in battery backup to 15 days
Serial Interface:	Surge Protected, RS485
Network Limitations:	32 drops 4000 feet at 9600 baud
Operating Temperature:	0°C - 49°C (32°F - 120°F)
Humidity:	0% - 95% Non-condensing
Factory Defaults:	Slave Mode, 12-hour Mode, Bright Mode

